

Application Number 10/559881
Response to Office Action dated 03/18/2008
Page 2

RECEIVED
CENTRAL FAX CENTER
JUN 18 2008

REMARKS

Applicant respectfully request favorable reconsideration of this application. Claims 1-10 are pending.

Claim Rejections - 35 USC § 103

Claims 1-6, 8, and 10 were rejected under 35 USC 103(a) as being unpatentable over Buon (US 4494548) and further in view of Nunomura et al. (US 7001355 B2). Applicant respectfully traverses the rejection.

Regarding claim 1, the rejection conceded that Buon does not teach a device that includes a 1,2-butylene glycol or 1,3-butylene glycol. The rejection also conceded that Nunomura et al. does not specifically mention 1,2-butylene glycol. The rejection stated that because 1,2-butylene glycol and 1,3-butylene glycol are isomers, it would have been obvious for one of ordinary skill in the art to substitute one isomer for another in order to achieve a predictable result. Applicant respectfully disagrees.

Buon teaches a device with a fill fluid. To work as intended, Buon's fill fluid must have certain characteristics. Buon teaches that the "fill fluid must also be capable of lubricating the mechanism which it contacts, i.e., the bearings 13 and 18, the cam 13, etc. and chemical compatible with the materials within the probe to which it is exposed as well as being electrically insulating. An example of such a fluid is composed of 71% propylene glycol and 29% Poly G-200" (column 2, lines 57-63). Further, Buon teaches that the fluid is sealed with a pair of O-rings in the internal body (see column 2, lines 64-65). Accordingly, Buon's device requires that the fluid be sealed inside the device to lubricate the mechanical parts of the device from within and further that the fluid must be electrically insulating.

Nunomura et al. does not teach a "fill fluid" that has the requirements that Buon teaches are necessary for the device to work as intended. Nunomura et al. teaches a viscous composition for applying on the skin (column 4, line 57). Nunomura et al. teaches that the viscous composition include a water-soluble humectant and an aqueous carrier. Nunomura et al. does not even suggest that the viscous composition can be used inside an ultrasonic device, let alone suggest that it is capable of lubricating mechanical parts, such as "bearings" and "cams" (as required according to Buon, see supra). Nunomura et al. teaches that the composition includes

Application Number 10/559881
Response to Office Action dated 03/18/2008
Page 3

"0.1% to about 30%" water-soluble humectant (column 11, line 14). The water-soluble humectant contains butylene glycol which is specifically and singularly defined, without alternatives, to be 1,3-butylene glycol (column 11, line 17, and again in line 38). Nunomura et al. teaches that 1,3-butylene glycol provides a moisturizing effect to skin without significantly deteriorating the penetration of skin lightening agents (column 11, lines 34-36). Further, the water-soluble humectant 1,3-butylene glycol is provided in an aqueous carrier comprising "at least about 70% water" (column 12, line 26). Accordingly, the composition taught in Nunomura et al. is not intended to be sealed inside a device to lubricate the mechanical parts of the device from within. Thus, filling Buon's device with the composition taught in Nunomura et al. would be contrary to the stated purpose of the composition in Nunomura et al. Therefore, there is no motivation to combine the two references.

Further, the rejection erroneously concluded that it would have been obvious for one of ordinary skill in the art to substitute one isomer for another in order to achieve a predictable result. Although it is known in the art that certain physical properties of particular isomers of butylene glycols are similar, for example, 1,3-butylene glycol, 1,4-butylene glycol, and 2,3-butylene glycol have similar physical properties, it is also known that 1,2-butylene glycol has physical properties that are significantly different from the other three isomers. The difference is generally attributed to the more hydrophobic nature of 1,2-butylene glycol compared to the other isomers of butylene glycol (see Hawrylak, Brent, et al. *Ultrasonic Velocity and Volumetric Properties of Isomeric Butanediols plus Water Systems*, Can. J. Chem. 76: 464-468 (1998), at 468). Further example is in the viscosities of 1,2-butylene glycol and 1,3-butylene glycol, which are significantly different from each other (see Table I of Hawrylak, Brent, et al., *Viscosity, Surface Tension, and Refractive Index Measurements of Mixtures of Isomeric Butanediols with Water*, Journal of Solution Chemistry, Vol. 27, No. 9, 1998: 827-841, at 829). As shown in Fig. 2 of Hawrylak et al., 1,3-butylene glycol (1,3-BTD), 1,4-butylene glycol (1,4-BTD), and 2,3-butylene glycol (2,3-BTD) show similar $\Delta\eta$ values while that of 1,2-butylene glycol (1,2-BTD) is clearly different from the other isomers (see Id, at 834; figure is shown below). Accordingly, because of these differences, one skilled in the art would understand that substituting 1,2-butylene glycol for 1,3-butylene glycol does not achieve a predictable result. Thus, it would not have been obvious for one of ordinary skill in the art to substitute 1,2-butylene glycol for 1,3-

Application Number 10/559881
Response to Office Action dated 03/18/2008
Page 4

butylene glycol. As noted above, Buon's device requires a "fill fluid" that is sealed inside the device to lubricate the mechanical parts of the device from within and further that the fluid must be electrically insulating. Nunomura et al. does not teach whether the "fill fluid" has these requirements that are necessary for the device to work as intended. Therefore, there is no motivation to combine the two references. Further, even if there was a motivation to use a 1,3-butylene glycol in Buon's device, there is no reference that teaches the use of 1,2-butylene glycol as a "fill fluid." Further, as stated above, it would not have been obvious for one of ordinary skill in the art to substitute 1,2-butylene glycol for 1,3-butylene glycol. Therefore, claim 1 is patentable over Buon in view of Nunomura et al. Claims 2-6, 8, and 10 are patentable for at least the same reasons as claim 1 from which they depend. Applicant respectfully requests a favorable reconsideration.

834

Hawrylak et al.




Fig. 2. Plot of $\Delta\eta$ vs. mole fraction of diol at 25°C.

Fig. 2 of Hawrylak et al., at 834 (1,2-BTD is 1,2-butylene glycol)

Application Number 10/559881
Response to Office Action dated 03/18/2008
Page 5

Claim 7 was rejected under 35 USC 103(a) as being unpatentable over Buon, in view of Nunomura et al., and further in view of Ludwig (Ludwig, George. The Velocity of Sound through Tissues and the Acoustic Impedance of Tissues. The Journal of the Acoustical Society of America, Nov. 1950: (22)(6) 862-866) and in view of Schafer (Schafer, Mark E et al. Use of Time Delay Spectrometry in Fluid Attenuation Measurement Ultrasonics Symposium, 1989: 973-976). Applicant respectfully traverses the rejection. Neither Ludwig nor Schafer remedy the deficiencies of Buon and Nunomura et al. stated above in regard to claim 1. Thus, claim 7 is patentable for at least the same reasons as claim 1 from which it depends.

Moreover, the rejection stated that Schafer teaches the acoustic attenuation properties of 1,3-butylene glycol and accordingly it would have been obvious for one of ordinary skill in the art to understand the attenuation properties of fluids as taught in Schafer and to modify the system of Buon and Nunomura et al. to include the desired fluid as taught in Schafer in order to chose the ideal fluid. Applicant respectfully disagrees.

Schafer et al. teaches that finding or choosing an ideal fluid that meets certain acoustic constraints that is also "non-corrosive, non-conductive, and have suitable dielectric and viscosity characteristics" is not only non-obvious, "it is nearly impossible" (Schafer et al., at 973, Part I). Schafer et al. also states that the results have a trend wherein "more viscous fluids generally showed higher levels of attenuation" (Schafer et al., at 975, Part V). Schafer et al. does not support this statement with any numerical values, graphs, or data. Accordingly, this statement is merely a general statement regarding an observed trend of the few tested fluids, not a theory that correlates fluid properties. This is supported by the fact that it is well known in the art that viscous fluids do not necessarily show higher levels of attenuation. For example, Selfridge (IEEE Transactions on Sonics and Ultrasonics, Vol. SU-32, No. 3, May 1985: 381-394) teaches attenuation values of certain fluids (indicated as LOSS(A=) on pages 388-390). Further, the viscosities of certain fluids are known in the art, see for example page 394 of Chronological Scientific Tables, vol. 75 (2002, edited by National Astronomical Observation of Japan). The following table shows several fluids' attenuations and viscosities, selected from the above two documents.

Application Number 10/559881
Response to Office Action dated 03/18/2008
Page 6

Liquids	CAS No.	Viscosity (10 ⁻³ Pa-s)	LOSS (A=)	Temperature (°C)
Acetone	67.64.1	0.31	54	25
Alcohol, methanol	67.56.1	0.543	30.2	25
Benzene	71.43.2	0.603	873	25
Alcohol, ethanol	61.17.5	1.084	48.5	25

As shown in the above table, acetone has a viscosity of 0.31 and attenuation of 54 while ethanol has a viscosity of 1.084 and attenuation of 48.5. Accordingly, acetone has lower viscosity than ethanol yet exhibits higher attenuation. Furthermore, ethanol has a higher viscosity than benzene, yet benzene has a substantially higher attenuation than ethanol. Accordingly, the examples above contradict the presumption relied in the rejection.

As shown above, it is known in the art that a fluid having lower viscosity than another fluid does not necessarily also have lower attenuation. Thus, it would not have been predictable that replacing 1,3-butylene glycol with 1,2-butylene glycol as an acoustic medium would result in the desirable attenuation. Accordingly, even if the viscosities of 1,2-butylene glycol and 1,3-butylene glycol were known, one skilled in the art would not be able to predict which would have higher attenuation. Thus, the rejection erroneously relied on this general statement to conclude that there is a relationship of viscosity to attenuation that would make one skilled in the art to predict that 1,2-butylene glycol would have lower attenuation than 1,3-butylene glycol.

The acoustic impedance of 1,2-butylene glycol is superior to and more desirable than 1,3-butylene glycol because the acoustic impedance of 1,2-butylene glycol is similar to the acoustic impedance of a living body (see page 8, lines 17-18 in the Specification). Because of this and other unexpected and superior acoustic characteristics of 1,2-butylene glycol, "an ultrasonic probe with high performance, high quality, and safety can be obtained. In particular, since 1,2-butylene glycol produces a small amount of ultrasonic attenuation, it is possible to improve the transmitting/receiving sensitivity for ultrasonic waves" (page 10, lines 12-15; also see Fig. 2). Further, Fig. 3 illustrates clearly the superior viscosity characteristics of 1,2-butylene glycol over that of 1,3-butylene glycol for use as an acoustic medium.

Application Number 10/559881
Response to Office Action dated 03/18/2008
Page 7

For at least the above reasons, claim 7 is patentable over Buon, in view of Nunomura et al., and further in view of Ludwig and in view of Schafer. Applicant respectfully requests a favorable reconsideration.

Claim 9 was rejected under 35 USC 103(a) as being unpatentable over Buon, in view of Nunomura et al., and further in view of Atala et al. Applicant respectfully traverses the rejection. Atala et al. does not remedy the deficiencies of Buon and Nunomura et al. stated above in regard to claim 1. Thus, claim 9 is patentable for at least the same reasons as claim 1 from which it depends. Applicant respectfully requests a favorable reconsideration.


In view of the above amendments and remarks, Applicant respectfully requests a Notice of Allowance. If the Examiner believes a telephone conference would advance the prosecution of this application, the Examiner is invited to telephone the undersigned attorney-of record, Douglas P. Mueller (Reg. No. 30,300), at (612) 455-3804.



Dated: June 18, 2008

Respectfully submitted,

HAMRE, SCHUMANN, MUELLER &
LARSON, P.C.
P.O. Box 2902
Minneapolis, MN 55402-0902
(612) 455-3800

By: 
Douglas P. Mueller
Reg. No. 30,300
DPM/ajk

Approximate Material Properties in Isotropic Materials

ALAN R. SELFRIDGE, MEMBER, IEEE

Abstract—A very important part of the design of ultrasonic transducers and ultrasonic measurement systems is the selection of materials. Typically, materials must be screened on the basis of their acoustic velocity, impedance, and attenuation. The final selection of a material is based upon many other factors, such as how well it adheres to epoxy, its linearity, or how much water it absorbs. This paper is intended to aid in the initial screening process. Some simple techniques for approximating these material properties are presented, and then an extensive table of the materials that have been measured or whose properties have been obtained from the references is given.

MEASUREMENT TECHNIQUES

THE FIRST STEP in the measurement of acoustic properties is to prepare a sample of the material of interest. Typically, the sample should have a thickness of approximately ten wavelengths at the measurement frequency and lateral dimensions at least ten times the thickness. The major surfaces should be flat and parallel to within about one percent or less of the thickness. If the material is cast, then special care must be taken to lap or sand the sample sufficiently to remove any variation in thickness due to shrinkage during cure.

Once the sample has been prepared, it is mounted in a measurement system such as the one shown in Fig. 1. The system consists of a water tank, an ultrasonic transducer, and a gimbal jig. The water tank shown has a glass-plate bottom to facilitate alignments in these and other experiments. The ultrasonic transducer used in this case was a Panametrics Videoscan Immersion Transducer (reference number V310), with a center frequency of 5 MHz and an element diameter of 0.25 in. Obviously one should choose a transducer with a center frequency close to the frequency of interest. The element in the transducer should be flat and have lateral dimensions at least ten times the acoustic wavelength in the water. This is important to avoid having to make corrections for diffraction. The gimbal jig in the measurement system is used to mount the sample and to align the major surfaces perpendicular to the ultrasound beam. It is desirable to design this jig such that the axes of rotation intersect near the front surface of the sample, and thereby keep the distance between the sample and the transducer nearly constant during alignment. Alignment is done after the sample is mounted by iteratively




Fig. 1. Measurement tank.




Fig. 2. Measurement system.

rotating the sample on the axes shown in Fig. 1 until the echo amplitudes are maximized.

The electronic system used to make the acoustic material measurements is shown in Fig. 2. This consists of a signal generator, a pair of diodes, the transducer, a receiver amplifier, and an oscilloscope. The signal generator must be capable of generating a gated sine wave with adjustable frequency and fairly small duty cycle, typically one percent or less. The small duty cycle is important so that the tonebursts can be short, typically five cycles, with a repetition rate low enough for all the reverberations in the measurement system to be well damped before the next excitation pulse is generated. It is helpful to place a pair of silicon diodes, back-to-back as shown in Fig. 2, in series with the signal generator. These have the effect of significantly improving the signal-to-noise ratio at the output of the system by removing the loading effect of the characteristic impedance of the signal generator from the transducer on receive, as well as isolating any low-level noise from the signal generator into the receiver amplifier. The

Manuscript received July 20, 1984; revised November 26, 1984.
The author is with Ultrasonic Devices, Inc., 2592 Middlefield Road, Palo Alto, CA 94301, USA.

0018-9537/85/0500-0381\$01.00 © 1985 IEEE

diodes are relatively unimportant on transmission when the signal levels are significantly higher than the threshold voltage of the diodes. One must be sure however that all of the received echos have amplitudes less than 1.0 V peak-to-peak to avoid any nonlinearities in the receiver amplifier. Linearity can be verified by adjusting the signal generator amplitude and observing that all received echos vary in proportion to one another. The receiver is typically a 20- to 40-dB high input impedance amplifier with a diode-protected input stage. A Panametrics 5052PR or 5052UA will work very well in this application. The oscilloscope must be capable of measuring time intervals and relative voltages with an accuracy of one percent or better.

Once the material specimen is prepared and the measurement system is assembled, the measurements are carried out as follows. The specimen is put into the gimbal jig and the ultrasonic transducer is mounted nearly normal to a major surface of the sample. The distance between the transducer and the specimen is chosen so that the transit time of an acoustic signal passing between the specimen and the transducer is about four to five times the transit time of an acoustic signal passing through the specimen. Next the signal generator is set to the frequency of interest and then gated to produce tonebursts approximately five cycles long. A train of echos due to reverberations of ultrasound in the specimen and water path between the specimen and the transducer should be observed on the oscilloscope. The amplitude of the echo train should then be maximized by manually adjusting the alignment of the specimen with respect to the ultrasonic beam using the gimbal jig.

If the material specimen is a typical epoxy with an impedance about twice that of water, and the measurement is set up and carried out as described earlier, then an echo train similar to that shown in Fig. 3 should be observed. The first four tonebursts in the received signal, denoted A_1 , A_2 , A_3 , and A_4 , are due to the wave that has traveled once through the water between the transducer and the specimen. A_1 is due to the reflection off the front face of the specimen, A_2 is due to the reflection off the back face of the specimen, and A_3 and A_4 are due to reverberations within the specimen. The next group of four tonebursts in the echo train are mainly due to triple transit echos, which traveled to the specimen, reflected back to the transducer, reflected back off the transducer, and traveled once again to the specimen, where reflections and reverberations occurred as before.

This rather complicated situation is analyzed using the schematic drawing in Fig. 4. We launch a signal from the acoustic transducer with a stress amplitude of one in the water. This signal propagates through the water path until it hits the impedance discontinuity at the sample-water interface. The reflection coefficient at this interface (R_1), is real and is given by (1). This equation and (2) can be derived from an example given by Auld [1, p. 130]. It is also given by Ristic [2, p. 11]. The portion of the signal that is reflected gives rise to the toneburst in the pulse train with the amplitude A_1 . Z_s is the acoustic impedance




Fig. 3. Measurement signal.




Fig. 4. Reverberation paths.

of the sample, and Z_w is the acoustic impedance of water:

$$R_1 = \frac{Z_s - Z_w}{Z_s + Z_w} \quad (1)$$

Some of the ultrasound continues on into the material sample. The stress amplitude of the transmitted wave is given by the transmission coefficient (T_1) given by

$$T_1 = \frac{2Z_s}{Z_s + Z_w} = 1 + R_1 \quad (2)$$

A portion of the ultrasound which continues into the sample is lost through the back face of the sample, and the rest is reflected by the back surface towards the front again. The reflection coefficient found at the back face is simply $-R_1$. When this portion of the ultrasound reaches the front face of the sample again, part of it is reflected back into the sample, but some of it is transmitted back into the water toward the transducer. The transmission coefficient here (T_2), is given by

$$T_2 = \frac{2Z_w}{Z_s + Z_w} = 1 - R_1 \quad (3)$$

This portion of the ultrasound, which has been to the back face of the sample and is now traveling back to the transducer, gives rise to the toneburst in the pulse train with amplitude A_2 .

Unless the acoustic transducer is perfectly matched to

the water, some of the ultrasound that returns to the transducer will be reflected back to the sample. This is the explanation for the subsequent groups of tonebursts observed in the pulse train shown in Fig. 3. The reflection coefficient off the transducer (R_2) is a complex function of frequency. This is why it is desirable to totally immerse the sample in water rather than the transducer in direct contact with it. If one is going to get accurate measurements of acoustic attenuation in a material, it is necessary to know the reflection coefficients on both sides of it.

While the sample is in the water tank and aligned, both the amplitudes A_1 and A_2 are recorded as well as the time delay between them, Δt . The time delay Δt corresponds to the propagation time of the acoustic signal in the sample. When measuring this time delay it should be noted that A_2 is inverted with respect to A_1 . This means that if one uses a positive-going first break as the time reference for A_1 , one should see a negative-going first break for A_2 . Very often lossy materials will distort A_2 and make time determinations difficult. Some oscilloscopes, such as the HP1743, allow you to overlap two separately delayed traces and thereby obtain time-delay measurements with a high degree of accuracy, provided you include the effect of the phase inversion.

The next step in the sequence of measurements is to remove the specimen from the water tank and measure its thickness d with a micrometer. With the propagation delay of the acoustic pulse through the specimen together with its thickness it is now possible to calculate the longitudinal plane wave velocity V in the specimen as

$$V = \frac{2d}{\Delta t} \quad (5)$$

The density of the sample is determined next. This can be done either by weighing a known volume of the sample or, if the volume cannot be readily determined by Archimedes' method. Archimedes' method requires the weight of an object in water W_w and its weight in air W_a . If the material has a density less than 1.0 g/ml, the sample will need to be tethered to a known weight so that its own negative weight in water can be calculated. After these two weights have been determined we calculate the density ρ as

$$\rho = \frac{W_a}{W_a - W_w} \quad (6)$$

The acoustic impedance of the same (Z_s) can not be calculated to be

$$Z_s = \rho V \quad (7)$$

Convenient units for expressing typical acoustic velocities are mm/ μ s. The velocity of water is very close to 1.5 mm/ μ s. Density is conveniently expressed in g/ml. The product of these two unit choices gives impedances in MRays (kg/(s \times m²)) $\times 10^6$. The impedance of water in these units is very conveniently 1.5. Given Z_s and Z_w , it is now possible to calculate R , T_1 , and T_2 , as given in (1)-

(3). Given these values it is possible to calculate what the ratio between A_2 and A_1 should be, given that there is no loss in the sample:

$$\text{calculated } \frac{A_2}{A_1} = T_1 * T_2 = 1 - R * * 2. \quad (8)$$

To actually obtain the loss (in dB/cm) in the sample material we compare the measured ratio of A_2 to A_1 to the above calculated ratio as in

$$\text{Loss in dB/cm} = 20 * \log \left(\frac{\text{Calculated } \frac{A_2}{A_1}}{\text{Measured } \frac{A_2}{A_1}} \right) / (2 * d). \quad (9)$$

If the previously mentioned rules specifying the size of the transducer and sample are followed, then the correction required to (9) due to diffraction is only on the order of 1 dB. Typically, this can be ignored when calculating approximate material properties. However it is highly recommended that after setting up the described measurement system, and before trusting the attenuation results obtained with it, a sample of plate glass or fused silica must be measured in which the loss is known to be very low relative to what can be measured with this technique. Obviously, if the measured value of the loss is more than about 1 or 2 dB/cm, the assumptions previously made concerning diffraction are suspect. This in turn means that the beam pattern of the transducer is suspect. Stanke [3] has actually measured materials which appeared to have acoustic gain rather than acoustic loss! The distorted beam pattern of the commercial transducer he was using was in fact responsible for this observation, rather than some more interesting miracle. To get over this problem special transducers were constructed using PVF2 on brass backings. The reflection amplitude of these devices was measured as a function of the distance between the transducer and a flat plate reflector, and this function was shown to be in good agreement with diffraction theory. More reasonable results were obtained using these transducers.

A program called PROPRT has been written which prompts the user to enter all of the necessary measured values and then calculates the material properties. It then prints the input and calculated values into a small area which can be cut out and taped onto the box enclosing the measured material. This program is listed in Fig. 5.

TABLES OF MATERIAL PROPERTIES

The following tables of material properties are included to aid the reader in the initial screening of materials. Abbreviations are used a great deal to obtain the compact format which is presented. Most abbreviations are explained in a table which follows the table of plastics; however, it is appropriate to at least define the abbreviations

384

IEEE TRANSACTIONS ON SONICS AND ULTRASONICS, VOL. SU-31, NO. 3, MAY 1985

```

c      program proprt
c      written by Alan Selfridge 8/12/81
c      This program calculates velocity, impedance, and loss in a material
c      from experimental measurements.
      real loss
      write(1,50)
50      format(' longitudinal wave transit time in microseconds ' $
      read(1,100) t
100     format(g0.8)
      write(1,150)
150     format(' amplitude of front face echo in water ' $
      read(1,100) a1
      write(1,200)
200     format(' amplitude of backface echo ' $
      read(1,100) a2
      write(1,250)
250     format(' weight in air in grams or zero to enter rho ' $
      read(1,100) wa
      if(wa.eq.0) go to 320
      write(1,300)
300     format(' weight in water in grams ' $
      read(1,100) ww
      rho = wa/(wa - ww)
      go to 340
320     write(1,330)
330     format(' density in g/cm3 ' $
      read(1,100) rho
      write(1,350)
340     format(' thickness in cm ' $
      read(1,100) d
      d = d*8.8256
      vl = 2*d/t
      cl = rho*vl
      r = (2l - 1.5)/(2l + 1.5)
      r2 = r*r
      loss = -20*log10(a2/(a1*(1 - r2)))/(d/5)
c      alpha is in db per cm      d/5 = 2*d in cm
      write(1,400)
400     format(' frequency in mhz ' $
      read(1,100) freq
      write(1,450) t, vl, al, rho, a2, z1, wa, freq, ww, loss, d
450     format(' t=,f0.2, usecs vl=,f0.2, cm/usec, /,
      1      ' al=,f0.2, volts rho=,f0.2, g/cm3, /,
      2      ' a2=,f0.2, volts z1=,f0.2, rhosv, /,
      3      ' wa=,f0.2, grams freq=,f0.2, mhz, /,
      4      ' ww=,f0.2, grams loss=,f0.2, db/cm, /,
      5      ' d=,f0.2, cm')
      stop
      end

```

Fig. 5. Program PROPR.

TABLE I
TABLES OF MATERIAL PROPERTIES

	SOLIDS and EPOXIES	VENDOR	v_L	v_S	ρ	z_L	σ	LOSS
CRC	Alusinox, rolled		6.42	3.84	2.70	17.33	8.355	
	ARC Res-in-all, 502/118, 5:1	ARC	2.67		1.33	3.61		
	ARC Res-in-all, 502/118, 9:1	ARC	2.73		1.35	3.68		
JA	Araldite 502/956	Ciba	2.62		1.16	3.84		
JA	Araldite 502/956, 180psi CSW	Ciba, Li	2.60		1.23	3.19		
JA	Araldite 502/956, 20psi CSW	Ciba, Li	2.54		1.39	3.32		
JA	Araldite 502/956, 30psi CSW	Ciba, Li	2.41		1.50	3.62		
JA	Araldite 502/956, 40psi CSW	Ciba, Li	2.34		1.67	3.86		
JA	Araldite 502/956, 50psi CSW	Ciba, Li	2.13		1.93	4.14		
JA	Araldite 502/956, 60psi CSW	Ciba, Li	2.10		2.24	4.70		
JA	Araldite 502/956, 70psi CSW	Ciba, Li	1.88		3.17	5.95		
JA	Araldite 502/956, 80psi CSW	Ciba, Li	1.72		4.71	9.11		
JA	Araldite 502/956, 50psi 325mesh W	Ciba, Li	2.16		2.86	6.17		
JA	Araldite 502/956, 60psi 325mesh W	Ciba, Li	1.97		2.78	5.34		
JA	Araldite 502/956, 70psi 325mesh W	Ciba, Li	1.82		3.21	5.84		
JA	Araldite 502/956, 80psi 325mesh W	Ciba, Li	1.64		4.35	7.45		
JA	Araldite 502/956, 90psi 325mesh W	Ciba, Li	1.52		8.48	12.81		
AS	Arsenic tri sulfide As2 S3	Ch	2.58	1.48	3.78	8.25	8.29	
N	Bearing babbitt		2.30		19.1	23.2		
CRC	Beryllium		12.89	8.88	1.87	24.18	8.846	
	Bismuth		2.2	1.1	9.8	21.5	8.33	
	Boron carbide		11.0		2.4	26.4		

SELFDRIDGE: APPROXIMATE MATERIAL PROPERTIES IN ISOTROPIC MATERIALS

385

TABLE I (Continued)

	SERIES and EPOXIES	VENDOR	V _L	V _S	P	Z _L	σ	CGSS
	Brass, yellow, 70 Cu, 30 Zn		4.78	2.18	8.64	48.6	0.39	
	Brick		4.3		1.7	7.4		
	Cadmus		2.8	1.5	8.6	24.8	0.38	
AS	Carbon, pyrolytic, soft, variable properties		3.31		2.21	7.31		
AS	Carbon, vitreous, very hard material	FI	4.25	2.68	1.47	6.26	0.17	
	Columbium (see Midsouth)							
KF	Concrete		3.4		7.6	8.9		
CRC	Copper, rolled		5.81	2.27	8.93	41.4	0.37	
AS	DER317, 9phr DEN28, 110phr W, r3	C,E	2.18	8.56	2.84	4.45	0.35	6.4 0 2
AS	DER317, 9phr DEN28, 115phr W, r3	C,E	1.93		2.57	4.58		
AS	DER317, 9phr DEN28, 910phr T1167, r3	C,E	1.58		7.27	10.91		13.2 0 2
AS	DER317, 18.5phr DEN28 rt, outgass	E	2.75		1.18	3.25		
AS	DER317, 18.5phr DEN28, 110phr W, r3	E,E	2.87		2.23	4.61		8.3 0 2
AS	DER317, 13.5phr apda, 50phr W, r1	C,D,E	2.48		1.68	3.84		
AS	DER317, 13.5phr apda, 100phr W, r1	C,D,E	2.19		2.83	4.44		
AS	DER317, 13.5phr apda, 250phr W, r1	C,D,E	1.84	8.93	3.4	4.4	0.33	
AS	DER332, 10phr DEN28, rt cure 48 hours	E	2.68		1.28	3.11		
AS	DER332, 10phr DEN28, 120phr alumina, r2	D,E	3.18	1.62	1.76	5.58	0.32	
AS	DER332, 16.5phr DEN28, 10phr alumina, r2	D,E	2.61		1.26	3.29		
AS	DER332, 18.5phr DEN28, 14phr alumina, r2	D,E	2.65		1.29	3.41		
AS	DER332, 18.5phr DEN28, 36phr alumina, r2	D,E	2.75		1.37	3.79		
AS	DER332, 11phr DEN28, 14phr alumina, r10	D,E	2.71		1.29	3.49		5.4 0 2
AS	DER332, 11phr DEN28, 150phr alumina, r2	D,E	3.25		1.63	5.95		
AS	DER332, 11phr DEN28, 150phr alumina, 50phr LPS, rt	D,E,T	2.35		1.72	4.85		23.7 0 2
AS	DER332, 14phr apda, 30phr LPS, 70C cure	D,E,T	2.59		1.25	3.24		8.3 0 2
AS	DER332, 15phr apda, 60C cure	D,E	2.68	1.15	1.21	3.25	0.37	6.7 0 2
AS	DER332, 15phr apda, 25phr LPS, 76C cure	D,E,T	2.55	1.18	1.24	3.16	0.36	7.4 0 1.3
AS	DER332, 15phr apda, 30phr LPS, 80C cure	D,E,T	2.66		1.24	3.38		6.8 0 2
AS	DER332, 15phr apda, 50phr alumina, 60C cure	D,D,E	2.8	1.43	1.49	4.19	0.32	
AS	DER332, 15phr apda, 80phr alumina, 80C cure	D,D,E	2.78	1.43	1.54	4.27	0.31	
AS	DER332, 15phr apda, SiC, r5	C,D,E	3.18		2.28	8.74		
AS	DER332, 15phr apda, SiC, 25phr LPS, r5	C,D,E,T	3.75		2.15	9.84		
AS	DER332, 15phr apda, 6 micron W, r5	C,D,E	1.75		6.45	11.3		
AS	DER332, 50phr V148, rt cure	E,GR	2.34	0.97	1.13	2.64	0.48	
AS	DER332, 64phr V148, rt cure	E,GR	2.56		1.13	2.65		
AS	DER332, 75phr V148, rt cure	E,GR	2.35		1.12	2.62		
AS	DER332, 180phr V148, rt cure	E,GR	2.32		1.18	2.55		
AS	DER332, 180phr V148, 30phr LPS, r9	E,GR,T	2.77		1.13	2.55		7.5 0 2, 11.2 0 2.3
AS	DER332, 180phr V148, 30phr LPS, r9	E,GR,T	2.36		1.16	2.71		9.4 0 2
AS	DER332, 180phr V148, 50phr LPS, r8	E,GR,T	2.32		1.13	2.63		12.0 0 2
AS	DER332, 50phr V148, 50phr St. Helens ash, 60C	E,GR,T	2.43		1.94	6.21		
CRC	Boraluminite 17S		6.32	3.13	2.79	17.63	0.34	
AS	Duxseal	JM	1.49		1.61	2.58		13.3 0 0.5
AS	Epoxy glue, EPI-1 or EPI-2, 100phr of B	Loc	2.44		1.18	2.68		9.4 0 5
	Epon 826, apda	Sh,D	2.828	1.23	1.21	1.4	0.45	
	Epotek 301	Ma	2.64		1.88	2.85		
	Epotek 330	Ma	2.57		1.14	2.94		
	Epotek H765	Ma	2.91		1.61	4.88		
AS	Epotek V6, 180phr of B, r6	Ma	2.61		1.23	3.21		6.5 0 2
AS	Epotek V6, 180phr of B, r7	Ma	2.55		1.23	3.14		8 0 2
AS	Epotek V6, 180phr of B, 20phr LPS, r6	Ma,T	2.68		1.25	3.25		6 0 2
AS	Epotek V6, 180phr of B, 20phr LPS, r7	Ma,T	2.53		1.26	3.22		6 0 2
	Fused silica	Dyna	5.96	3.78	2.28	13.1	0.17	6.28-3 0 2
M	Beralumite, sp-937.4C, transparent to infrared	C	5.41		5.47	29.6		
	Glass, corning E21S sheet	Darn	5.46		2.49	14.89		
	Glass, crown	RG	5.1	2.8	2.26	11.4	0.28	
	Glass, FCS	Schott	4.81	2.83	2.26	11.1	0.243	
	Glass, FK6 large window order	Schott	4.43	2.34	2.28	10.1	0.23	
AE	Glass, flint		4.5		3.6	16.8		
	Glass, sacor machinable code 945B	Lee	5.51		2.54	14.8		
	Glass, pyrex	Corn	5.64	3.28	2.24	13.1	0.24	
AE	Glass, quartz		5.5		2.2	12.		
AE	Glass, silica		5.9		2.2	13.8		
	Glass, soda flint		6.88		2.24	13.4		
	Glass, V1R	Schott	4.38		2.58	18.5		
RB	Glucose		3.28		1.56	5.8		
CRC	Gold, hard drawn		3.24	1.28	19.7	43.8	0.42	
AM	Granite		6.5		4.1	26.8		
M	Hafnia, ep715BC, used in reactor control rods C		3.84		13.29	51.8		

386

IEEE TRANSACTIONS ON SONICS AND ULTRASONICS, VOL. SU-32, NO. 3, MAY 1985

TABLE I (Continued)

	SOLIDS and EP0XIES	VEKDOE	ν_L	ν_S	ρ	Z_L	σ	LOES
	Hydrogen, solid at 4.2K		2.19		0.089	0.19		
	Hysol ES 4212, 1:1	H	2.32		1.58	3.49		
	Hysol ES 4412, 1:1	H	2.82		1.68	3.39		
EP	Hysol CS-4143/3404	H	2.05		1.58	4.52		
EP	Hysol CS-4183/3561	H	2.92		1.48	4.3		
EP	Hysol CS-4183/3561, 15phr CSM	H, Li	2.62		1.88	4.7		
EP	Hysol CS-4183/3561, 30phr CSM	H, Li	2.49		2.14	5.33		
EP	Hysol CS-4183/3561, 45phr CSM	H, Li	2.38		2.66	6.10		
EP	Hysol CS-4183/3561, 57.5phr CSM	H, Li	2.16		3.27	7.04		
EP	Hysol ES-2839/3404	H	2.59		1.18	3.83		
EP	Hysol ES-2839/3404	H	2.59		1.13	2.92		
EP	Hysol ES-2839/3469	H	2.61		1.17	3.07		
EP	Hysol ES-2839/3561	H	2.33		1.18	3.8		
	Inconel		5.7	3.8	8.28	47.2	0.31	
	Inconel	I	2.56		7.5	18.7		
	Iron		5.9	3.2	7.49	46.4	0.29	
	Iron, cast		4.6	2.6	7.22	33.2	0.27	
	Lead		2.2	0.7	11.7	24.6	0.44	
	Lead antimonate	Kera	3.38		4.2	28.3		q=13
	Lithium niobate, 36 rot, Y-cut	CI	7.08		4.7	33.8		
	Magnesium, various types listed in ref 'M'		5.8	3.0	1.738	18.0	0.32	
AE	Marble		3.8		2.8	18.5		
AS	MF-198	EC	2.67		4.45	11.88		15.9 & 4.0
	Molybdenum		6.3	3.4	18.8	63.1	0.29	
	Monel		5.4	2.7	8.82	47.6	0.33	
AS	Murata PZT	Mura	4.72		7.95	37.3		
	Nickel		5.6	3.0	8.84	49.3	0.30	
M	Niobium, n.p.= 246BC	C	4.92	2.18	8.37	42.2	0.39	
AE	Paraffin		1.5		1.5	2.3		
CRC	Platinum		3.26	1.73	21.4	49.8	0.32	
AE	Polyester casting resin	Tap	2.29		1.87	2.86		
	Porcelain		5.9		2.3	13.8		
	FSN, potassium sodium niobate		6.94		4.46	31.8		
	Pressed graphite		2.4		1.8	4.1		
	PIT SM. Vernitron	EBL	4.44		7.43	33.0		
	PWF2	Ja	2.38		1.79	4.2		q=18
LF	Quartz, Y-cut	VF	5.75	2.2	2.65	15.1	0.42	
M	Rubidium, mp=39.9, a 'getter' in vacuum tubes	C	1.26		1.53	1.93		
M	Salt, NaCl, crystalline, 1 direction		4.78		2.17	18.37		
	Sapphire, aluminum oxide, 2 axis		11.15		3.98	44.46		
DP	Scotch tape 2.5 mils thick	Ja	1.9		1.16	2.89		
AS	Scotchcast 185233, 38phr B. rt cure	Ja	2.48		1.49	3.78		3.0 & 1.3
	Scotchply SF682, a laminate with fibers	Ja	3.25		1.99	6.24		
	Scotchply IF 241	Ja	2.84		0.65	1.84		
AS	Silicon, very anisotropic, values are approx.		8.43	5.84	2.34	19.3		
	Silicon carbide		6.66		13.8	91.8		
	Silicon nitride		11.8	6.25	3.27	36.8	0.28	
	Silver		3.6	1.6	18.6	38.0	0.38	
AS	Silver epoxy, e-solder 2822	Acce	1.9	0.98	2.71	5.14	0.32	16 & 2
AE	Slate		4.5		3.8	13.5		
	Steel, mild		5.9	3.2	7.88	46.8	0.29	
	Steel, stainless 347, $E_s = 21.5$		5.79	3.18	7.89	45.7	0.38	
	Stycast 1266, rt cure	EC	2.22		1.19	2.64		
	Stycast 1267	EC	2.57		1.16	3.88		4.6 & 3.8
JA	Stycast 1978, tests 8189.08/lb	EC	3.2		1.98	6.88		
AS	Stycast 2651-48 9phr cat9 rt cure	EC	2.77		1.3	4.16		
AS	Stycast 2651-48 9phr cat9, 18phr SiC	EC,C	2.88		1.37	4.33		
AS	Stycast 2651-48 9phr cat9, 20phr SiC	EC,C	2.95		1.63	4.82		
AS	Stycast 2651-48 9phr cat9, 25phr SiC	EC,C	2.98	1.50	1.67	4.83	0.32	
	Stycast 2741, 1:1	EC	2.29		1.17	2.68		
M	Sulphur, 9 isotropic forms exist, mp approx 112C		1.33		2.0	2.7		
M	Tantalum, mp=2796C, very inert, hard	C	4.18	2.98	18.6	54.8		
M	Thorium, mp=1780C, fissionable, high melting oxide		2.48	1.56	11.3	33.2	0.134	
AS	Uspox epoxy	Tap	2.48		1.11	2.76		
AS	Techform EA789, brittle material	Tech	2.63		1.28	3.14	4.6 & 2, 3.2 & 2.5	
	Teflon		1.39		2.14	2.97	3.9 & 5	
	Tin		3.3	1.7	7.3	24.2	0.31	
	Titanium, mp=1723C		6.1	3.1	4.18	27.3	0.32	

SELFREDGE: APPROXIMATE MATERIAL PROPERTIES IN ISOTROPIC MATERIALS

387

TABLE 1 (Continued)

	SOLIDS and EP0XIES	VENDOR	V					LOSS
			V_L	V_S	P	I_L	σ	
M	Vitriol carbide, ap=3148C	C	8.27	5.16	5.15	42.6		
	Tracom 481 ST	Tr	2.97		1.62	4.82		
	Tracom 2135 D	Tr	2.45		1.83	2.52		
	Tracom 2145 D	Tr	2.37		1.85	2.58		
	Tracom 2167 E	Tr	2.82		1.19	2.41		
	Tracom 3611	Tr	2.12		1.7	2.54		
	Tongster	E	5.2	2.9	19.4	101.0	8.27	
M	Unacrinolite	proprietary						
	Unacrinolite	C	3.4	2.0	18.5	65.8	0.24	
	Unacrinolite	C	3.18		18.96	58.7		
	Unacrinolite, ap=1298C	C	6.88	2.78	6.87	36.2	8.32	
	Wood, cork		3.5		0.24	0.12		
	Wood, cal		4.8		0.72	2.9		
	Wood, pine		3.5		0.45	1.57		
M	Wood, green var., granular		4.2	2.4	7.8	29.6	8.28	
	Wood, white		6.48	2.95	5.68	58.4	8.37	
	Zirconium		4.72	2.36	9.36	44.2		
	Zirconium, ap=1552C, used in zirconium alloy		4.65	2.25	6.45	58.1	8.35	
	PLASTICS	VENDOR	V					LOSS
			V_L	V_S	P	I_L	σ	
AS	ABS, Beige	Port	2.27		1.83	2.31		11.185
AS	ABS, Black, Injection molded	Port	2.25		1.85	2.34		18.985
AS	ABS, Grey, Injection molded	Port	2.17		1.87	2.32		11.385
AS	Acrylic, Clear, Plexiglas S Safety Glazing	Robt	2.75		1.19	3.26	0.48	6.485
AS	Acrylic, Plexiglas MI-7	Robt	2.61		1.18	3.88	0.48	12.485
AS	Acrylic, Plexiglas MI-7	HC	1.59		1.48	3.63		
AS	Cellulose Butyrate		2.14		1.19	2.56		21.985
AS	Delrin, Black	D	2.43		1.42	3.45		38.385
JA	Ethyl vinyl acetate, VE-638 (18% Acetate)	USI	1.88		0.94	1.69		
JA	Ethyl vinyl acetate, VE-634 (28% Acetate)	USI	1.68		0.95	1.68		
JA	Kydex, PVC Acrylic Alloy Sheet	Robt	2.218		1.35	2.99		
AS	Lexan, Polycarbonate	GEF	2.38		1.20	2.75		23.285
AS	Lustran, SAN	Robt	2.51		1.86	2.48		3.185
AS	Nylon	D	2.54		1.18	3.88		
AS	Kodak PETG, 6763, Copolyester	Kodak	2.34		1.27	2.77		28.885
AS	Nalcapas	AMP	2.98		1.7	4.93		7.282.5
AS	Nylon, 6/6		2.6	1.1	1.12	2.9	0.39	2.985
AS	Nylon, Black, 6/6	Port	2.77		1.14	3.15		16.885
AS	Polycarbonate, Black, Injection molded	GEF	2.27		1.22	2.77		22.185
AS	Grade 141R, Color No. 701, "Lexan"							
AS	Polycarbonate, Blue, Injection molded	Robt	2.26		1.20	2.72		23.585
AS	Grade K-148, Color No. 8887, "Nylon"							
AS	Polycarbonate, Clear, Sheet Material	Port	2.27		1.18	2.69		24.985
CRC	Polyethylene		1.95	0.34	0.98	1.76		
	Polyethylene, high density, LD-661	USI	2.43		0.96	2.33		
	Polyethylene, low density, LD-117	USI	1.95	0.54	0.92	1.75	0.46	2.485
	Polyethylene oxide, MSR 381	HC	2.25		1.21	2.72		
	Polypropylene, Profax 6432, Marbles	USI	2.74		0.88	2.48		5.185
AS	Polypropylene, White, Sheet Material	Port	2.66		0.89	2.36		18.285
AS	Polystyrene, "Fostarene 58"	Robt	2.45		1.84			
AS	Polystyrene, "Lustran", Injection molded	Robt	2.32		1.84	2.42		3.685
	Resin 6H/55-2828-347							
	Polystyrene, Styron 666	E	2.48	1.13	1.85	2.52	0.35	1.885
	Polyvinyl butyral, Butacite, used to laminate safety glass together	D	2.33		1.11	2.68	0.37	
	FSD, Polysulfone	HC	2.24		1.24	2.76		4.2882
AS	PVC, Grey, Rod Stock, Normal Impact Grade	Port	2.38		1.38	3.27		11.285
AS	Styrene Butadiene, KR 85 Nd	Phil	1.92		1.82	1.95		24.385
AS	TPI-01843, Diethyl pentane polymer	HP	2.22		0.83	1.84		3.881.3,4,484
AS	Valox, Black, (glass filled nylon)	EE	2.53		1.52	3.83		15.785
AS	Vinyl, Rigid		2.25		1.33	2.96		12.885
	RUBBERS	VENDOR	V					LOSS
			V_L	V_S	P	I_L	σ	
	Isoprene LV-578	Uni	1.68		1.16	2.94		
	Butyl rubber		1.88		1.11	2.8		

388

IEEE TRANSACTIONS ON SONICS AND ULTRASONICS, VOL. SU-32, NO. 3, MAY 1985

TABLE I (Continued)

RUBBERS		VENDOR	V_L	ρ	Z_L	LOSS
AS	Dow Silastic Rubber GP45, 45 Durometer	NPC	1.82	1.14	1.16	23.484
AS	Dow Silastic Rubber GP70, 70 Durometer	NPC	1.84	1.25	1.30	35.784
AS	Ecogel 1263, 180PMA OF 8, octagase, GRC	EC	1.96	1.18	2.14	33.482
AS	Ecogel 1263, 180PMA OF 8, 180PMA Alusins, F8	EC,P	1.70	1.48	2.33	>24,881.3
AS	Ecogel 1263, 180PMA OF 8, 1942PMA 11167, R4	EC,C	1.32	9.19	12.16	1488.4
	Ecothane CPC-39	EC	1.53	1.86	1.63	
	Ecothane CPC-41	EC	1.52	1.81	1.54	
	Neoprene		1.6	1.31	2.1	
AS	Pellathane, Thermoplastic Brethane Rubber	Woj	2.18	1.20	2.62	32.885
	550 Durometer					
AS	Polyurethane, RP-6480	Gal	1.76	1.11	1.96	46.184
BS	Polyurethane, RP-6480	REN	1.58	1.34	1.56	
BS	Polyurethane, RP-6481	REN	1.65	1.07	1.74	
BS	Polyurethane, RP-6482	REN	1.77	1.83	1.91	
BS	Polyurethane, RP-6483	REN	1.87	1.18	2.85	
BS	Polyurethane, RP-6485	REN	2.89	1.38	2.54	
BS	Polyurethane, RP-6410	REN	1.33	1.84	1.38	
BS	Polyurethane, RP-6413	REN	1.65	1.84	1.71	
BS	Polyurethane, RP-6414	REN	1.78	1.85	1.86	
BS	Polyurethane, RP-6422	REN	1.60	1.84	1.64	
AS	PR-1281-Q CREDITOR, PHG 18, RT Cure	PRC	1.45	1.19	2.59	12.282
	RTV-11	GE,RS	1.85	1.18	1.24	2.539.8
	RTV-21	GE,RS	1.81	1.31	1.32	2.648.8
	RTV-39	GE	1.97	1.45	1.41	2.818.8
	RTV-41	GE,RS	1.81	1.31	1.32	3.248.8
	RTV-68	GE,RS	0.96	1.47	1.41	2.888.8
	RTV-77	GE	1.82	1.33	1.36	3.288.8
	RTV-98	GE	0.96	1.5	1.44	4.288.8
	RTV-112	GE,RS	0.74	1.85	0.99	
	RTV-116	GE,RS	1.82	1.18	1.12	
	RTV-118	GE,RS	1.85	1.84	1.87	
	RTV-511	GE,RS	1.11	1.16	1.31	2.588.8
AS	RTV-540	GE,RS	0.99	1.41	1.48	2.288.8, 6.482
	RTV-577	GE,RS	1.88	1.35	1.46	3.888.8
	RTV-682	GE	1.16	1.82	1.18	4.3588.8
	RTV-615, use with 4155 primer	GE,RS	1.89	1.82	1.18	188.8
	RTV-614	GE,RS	1.84	1.22	1.29	2.288.8
	RTV-638	GE,RS	1.85	1.24	1.32	
BF	Gilly Putty, very lossy, hard to measure		1.8	1.2	1.9	
JA	Sylgard 178, a silicon rubber		0.974	1.38	1.34	
JA	Sylgard 182	E	1.827	1.85	1.87	
JA	Sylgard 184	E	1.827	1.85	1.84	
JA	Sylgard 186	E	1.827	1.12	1.15	
LIQUIDS		VENDOR	V_L	ρ	Z_L	LOSS
M	Acetate, butyl		1.27		0.871	1.82
M	Acetate, ethyl, C4H8O2		1.19		0.988	1.859
M	Acetate, methyl, C3H6O2		1.21		0.934	1.131
M	Acetate, propyl		1.18		0.891	1.85
LD	Acetone, (CH3)2CO at 25C		1.174	-4.5	0.791	1.97 A=54.8
M	Acetonitrile, C2H3N		1.29		0.783	1.81
M	Acetonyl acetone, C4H8O2		1.48		0.729	1.359
M	Acetylendichloride, C2H2Cl2		1.82		1.26	1.288
M	Alcohol, butyl, C4H9OH at 38C		1.24		0.618	1.883 A=74.3
CRC	Alcohol, ethanol, C2H5OH, at 25C		1.287	-4.8	0.79	0.95 A=48.5
M	Alcohol, isopropyl, C3H7OH		1.45		1.135	1.645
LD	Alcohol, isopropyl, 2-Propanol, at 28C		1.17		0.786	0.928 A=92
CRC	Alcohol, methanol, CH3OH, at 25C		1.183	-3.2	0.791	0.872 A=38.2
M	Alcohol, propyl, C3H7OH at 38C		1.22		0.884	0.983 A=64.5
M	Alcohol, t-butyl, C4H9OH		1.28		0.818	0.976
M	Alkane 13, C15H24		1.32		0.888	1.132
M	Aniline, C6H5NH2		1.69		1.822	1.675
DR	Argon, liquid at 87K		0.848		1.43	1.28 A=15.2
CRC	Benzene, C6H6, at 25C		1.295	-4.65	0.87	1.12 A=873
M	Benzol		1.33		0.878	1.16
M	Benzol, ethyl		1.34		0.868	1.14
M	Bromobenzene C6H5Br at 27C		1.167		1.327	1.776 A=1.63
M	Bromofluor, CBrF3		0.92		2.898	2.678

SELFRIDGE: APPROXIMATE MATERIAL PROPERTIES IN ISOTROPIC MATERIALS

389

TABLE I (Continued)

	LIQUIDS	VENDOR	ρ_L	$\Delta\rho/\rho_L$	P	T_L	LOGS
M	t-Butyl chloride, C4H9Cl		0.78		0.84	0.827	
M	Butyrate, ethyl		1.17		0.877	1.03	
M	Carbitol, C4H10O3		1.44		0.998	1.431	
CRC,M	Carbon disulphide, CS2 at 25C		1.149		1.26	1.448	
DR	Carbon disulphide, CS2, 25C, 3 GHz		1.318		1.221	1.65	A=18.1
CRC,M	Carbon tetrachloride, CCl4, at 25C		0.926	-2.7	1.394	1.48	A=338
M	Casius at 28.3C the melting point	C	0.967		1.09	1.02	
LB	Chloro-benzene, C6H5Cl, at 22C		1.384		1.186	1.442	A=167
M	Chloro-benzene, C6H5Cl		1.38		1.18	1.432	
CRC,M	Chloroform, CHCl3, at 25C		0.987	-3.4	1.49	1.47	
M	Cyclohexanol, C6H12O		1.45		0.962	1.48	
M	Cyclohexanone, C6H10O		1.42		0.948	1.391	
M	Diacetyl, C4H6O3		1.24		0.99	1.222	
M	Dichloroisobutane (1,3), C4H8Cl2		1.22		1.14	1.378	
M	Diethyl ketone		1.31		0.813	1.07	
M	Dimethyl phthalate, C6H4(COOCH3)2		1.46		1.29	1.758	
M	Dioxane		1.38		1.033	1.425	
CRC,M	Ethanol oxide, C2H7NO, at 25C		1.774	-3.6	1.018	1.755	
CRC,M	Ethyl ether, C4H10O, at 25C		0.965	-0.67	0.713	0.7823	
M	d-Fenchone		1.32		0.94	1.241	
M	Fluorosilicone oil, Dow FS-1265		0.76				
M	Formamide, CH3NO		1.62		1.134	1.042	
M	Formic acid, C2H4O2		1.45		1.157	1.678	
3a	Fluorinert FC-48	3a	0.648		1.06	1.19	
3a	Fluorinert FC-78	3a	0.587		1.14	1.33	
3a	Fluorinert FC-72	3a	0.512		1.68	0.84	
3a	Fluorinert FC-75	3a	0.585		1.76	1.02	
3a	Fluorinert FC-77	3a	0.595		1.78	1.05	
3a	Fluorinert FC-184	3a	0.575		1.76	1.01	
3a	Fluorinert FM-43	3a	0.655		1.05	1.21	
LB	Fluoro-benzene, C6H5F, at 22C		1.18		1.024	1.285	A=317
AS	Freon, TF	VWR	0.716		1.37	1.12	
DR	Gallium at 30C up to 28.8 expands 3% when it freezes		2.67		0.09	17.5	A=1.58
M	Gasoline		1.25		0.983	1.08	
CRC	Glycerin, CH2OHCH2CH2OH, at 25C		1.261	-2.2	1.26	2.348	
M	Glycol, butylene (2,3)		1.49		1.019	1.511	
M	Glycol, diethylene, C4H10O3		1.58		1.116	1.778	
CRC	Glycol, ethylene, 1,2-ethanediol, at 25C		1.658	-2.1	1.113	1.845	A=128
JA	Glycol, ethylene, Preston II	Preston	1.59		1.189	1.76	
JA	Glycol, polyethylene 288	SW	1.62		1.037	1.75	
JA	Glycol, polyethylene 488	SW	1.62		1.06	0.71	
M	Glycol, polypropylene (Polyglycol P-488) at 38C		1.39				
M	Glycol, polypropylene (Polyglycol P-1288) at 38C		1.38				
M	Glycol, polypropylene (Polyglycol E-288) at 29C		1.57				
M	Glycol, tetraethylene, C8H18O6		1.58		1.12	1.784	
M	Glycol, triethylene, C6H14O4		1.61		1.123	1.01	
BR	Helium-4, liquid at 0.4K		0.238		0.147	0.035	A=1.73
BR	Helium-4, liquid at 2K		0.227		0.145	0.033	A=78
DR	Helium-4, liquid at 4.2K		0.183		0.126	0.023	A=226
M	n-Hexane, C6H14, liquid at 38C		1.183		0.659	0.727	A=87
M	n-Hexanol, C6H14O		1.38		0.919	1.063	
AS	Honey, sue bee orange		2.03		1.42	2.09	
	Hydrogen, liquid at 20K		1.19		0.07	0.08	A=5.6
LB	Iodo-benzene, C6H5I, at 22C		1.184		1.183	2.012	A=242
M	Isopentane, C5H12		0.992		0.62	0.615	
CRC,M	Kerosene		1.324	-3.6	0.61	1.072	
M	Linalool		1.48		0.884	1.23	
CRC	Mercury at 25.0C		1.458		13.5	19.58	A=5.3
M	Mesityloxide, C6H6O2		1.31		0.85	1.115	
M	Methylcyclopentane		1.21		0.885	0.972	
M	Methylene iodide		0.93				
M	Methyl naphthalene, C13H10		1.31		1.050	1.645	
M	Monochlorobenzene, C6H5Cl		1.27		1.107	1.411	
M	Morpholine, C4H8NO		1.44		1.08	1.442	
DR	Neon, liquid at 27K		0.688		1.28	0.72	A=23.1
LB	Nicotin, C10H14N2, at 28C		1.49		1.01	1.585	
CRC,M	Nitrobenzene, C6H5NO2, at 25C		1.463	-3.6	1.28	1.764	
DR	Nitrogen, N2, liquid at 77K		0.868		0.08	0.68	A=13.0
M	Nitrosobenzene, C6H5NO		1.33		1.13	1.584	

390

IEEE TRANSACTIONS ON SONICS AND ULTRASONICS, VOL. SU-32, NO. 3, MAY 1985

TABLE I (Continued)

	LIQUIDS	VENDOR	V_L	$\Delta V/\Delta T$	ρ	$1/\rho$	$1/\rho^2$
JA	Oil, baby	J&J	1.43		0.821	1.17	
CRC, R	Oil, castor, C31H60O10 @ 25C		1.477	-3.6	0.969	1.431	
SD	Oil, castor, @ 26.2C @ 4.224 Mc		1.587		0.942	1.428	A=18120.
JA	Oil, corn	Mazola	1.46		0.922	1.34	
N	Oil, diesel		1.25				
N	Oil, gravity fuel AA		1.49		0.99	1.472	
JA	Oil, linseed		1.46		0.94	1.37	
N	Oil, linseed		1.77		0.922	1.63	
JA	Oil, mineral, light	Diamond	1.44		0.825	1.19	
JA	Oil, mineral, heavy	Diamond	1.44		0.843	1.23	
JA	Oil, olive		1.445		0.918	1.32	
N	Oil, paraffin		1.42		0.835	1.86	
JA	Oil, peanut	Planter	1.436		0.914	1.31	
N	Oil, SAE 20		1.74		0.879	1.51	
	Oil, SAE 30		1.7		0.88	1.5	
JA	Oil, silicon Dow 200, 1 centistoke	DC	0.96		0.818	0.74	
JA	Oil, silicon Dow 200, 10 centistoke	DC	0.968		0.948	0.91	
JA	Oil, silicon Dow 200, 100 centistoke	DC	0.98		0.968	0.95	
JA	Oil, silicon Dow 200, 1000 centistoke	DC	0.99		0.972	0.96	
ED	Oil, silicon Dow 710 @ 28C	DC	1.352		1.11	1.58	A=6200.
JA	Oil, safflower		1.45		0.90	1.39	
JA	Oil, soybean	Messco	1.43		0.93	1.32	
N	Oil, sperm		1.44		0.89	1.268	
JA	Oil, sunflower		1.43		0.92	1.34	
N	Oil, transformer		1.39		0.92	1.28	
JA	Oil, wintergreen (methyl salicylate)	CVS	1.38		1.16	1.68	
DR	Oxygen, O2, liquid at 98K		0.988		1.11	1.0	A=9.9
N	Paraffin at 15C		1.38				
N	n-Pentane, C5H12, liquid at 15C		1.027		0.626	0.642	A=100
N	Polypropylene oxide (Ambflo) at 38C		1.37				
N	Potassium at 180C, mp=63.7C see 'N' for other temps		1.82		0.83	1.51	
N	Pyridine		1.41		0.982	1.39	
N	Sodium, liquid at 380C, (see 'N' for other temps)		2.42		0.81	21.32	
N	Solvent 43		1.37		0.877	1.282	
AS	Sonotrack couplant	Echo	1.62		1.04	1.68	
N	Tallow at 16C		0.39				
N	Thallium at mp=303.5C, used in photocells	C	1.62		11.9	19.5	
N	Trichloroethylene		1.05		1.05	1.18	
CRC	Turpentine, at 25C		1.255		0.88	1.104	
N	Urethyl BBS		1.35		0.87	1.171	
N	Water, heavy, 820		1.49		1.184	1.54	
N	Water, liquid at 20C		1.48		1.00	1.483	
CRC, DR	Water, liquid at 25C		1.4967	2.4	0.998	1.494	A=22
	Water, liquid at 30C		1.589		1.00	1.589	A=19.1
DR	Water, liquid at 60C, temps up to 500F listed in 'CRC'		1.95		1.08	1.55	A=16.9
N	Water, salt 101		1.47				
N	Water, salt 151		1.53				
N	Water, salt 201		1.68				
CRC	Water, sea, at 25C		1.531	2.4	1.023	1.569	A=22.8
DR	Xenon, liquid at 166K		0.638		2.86	1.89	
CRC, N	Xylene Hexafluoride, C6H5F6, at 25C		0.879		1.37	1.222	
N	n-ylol, C6H18		1.32		0.864	1.145	

	GASES	VENDOR	V_L	$\Delta V/\Delta T$	$\rho \times 10^3$	$1/\rho^2 \times 10^3$	$1/\rho^3$
ARC	Acetone vapor, C3H6O at 77.1C		0.237	0.33			
CRC	Air, dry at 2C		0.33145	0.59	1.293	0.4286	
N	Air, at 60.73 atm		0.332				
N	Air, at 60.73 atm		0.332				
N	Air, at 60.73 atm		0.331				
N	Air, at 20C		0.344				
N	Air at 100C		0.386				
N	Air at 500C		0.353				
ARC	Ammonia, NH3 at 0C		0.415		0.771	0.320	
CRC	Arson at 0C		0.519	0.56	1.783	0.569	
CRC	Benzene vapor, C6H6 at 57.1C		0.282	0.3			
CRC	Carbon monoxide, CO at 0C		0.338	0.6	1.25	0.423	
CFC	Carbon dioxide, CO2 at 0C		0.259	0.4	1.977	0.512	

SELFRIE: APPROXIMATE MATERIAL PROPERTIES IN ISOTROPIC MATERIALS

391

TABLE I (Continued)

	NAME	LENGTH	V	W/D	POD	LOD	LOSS
M	Carbon disulfate		0.189				
CAC	Carbon tetrachloride vapor, CCl ₄ at 97.1C		0.145				
CAC	Chlorine at 8C		0.285		3.216	0.662	
CAC	Chloroform, CHCl ₃ at 97.1C		0.171	0.24			
CAC	Deuterium at 8C		0.970	1.6	0.19	0.1691	
CAC	Ethane, C ₂ H ₆ at 8C		0.308		1.356	0.418	
CAC	Ethylene, C ₂ H ₄ at 8C		0.317		1.268	0.408	
CAC	Ethanol vapor, C ₂ H ₅ OH at 97.1C		0.269	0.4			
CAC	Ethyl ether, C ₂ H ₅ OC ₂ H ₅ at 97.1C		0.286	0.3			
CAC	Helium at 8C		0.965	0.8	0.178	0.172	
CAC	Hydrogen at 8C		1.284	2.2	0.8899	0.1154	
CAC	Hydrogen bromide, HBr at 8C		0.280		3.58	0.789	
CAC	Hydrogen chloride, HCl at 8C		0.296		1.639	0.485	
CAC	Hydrogen iodide, HI at 8C		0.157		3.66	0.809	
CAC	Hydrogen sulfide, H ₂ S at 8C		0.289		1.537	0.445	
CAC	Methane, CH ₄ at 8C		0.438		0.7168	0.388	
CAC	Methanol vapor, CH ₃ OH at 97.1C		0.335	0.46			
CAC	Neon at 8C		0.435		0.968	0.392	
CAC	Nitric oxide, NO at 18C		0.324		1.34	0.434	
CAC	Nitrogen, N ₂ at 8C		0.334	0.6	1.251	0.418	
CAC	Nitrous oxide, N ₂ O at 8C		0.263	0.5	1.977	0.528	
CAC	Oxygen, O ₂ at 8C		0.316	0.56	1.429	0.451	
M	Oxygen, O ₂ at 28C		0.328		1.32	0.433	
CAC	Sulfur dioxide, SO ₂ at 8C		0.215	0.47	2.927	0.623	
M	Water vapor at 8C		0.481				
M	Water vapor at 100C		0.485				
CAC	Water vapor at 174C		0.494				

VENDOR ABBREVIATIONS

3a	Bay Area, (415)257-2244, Los Angeles, (213)726-6385
ACAP	Acme Chemicals, PO Box 1484, New Haven, Conn. 06503, (203)562-2171
AMD	AMD Engineering, Rockland, N.Y. 02378
Roe	American Hoechst Corp., Tostin, Ca. (714)738-5851
AMPL	AMPL Prochal, Paris, France
B	Brinkman Instruments Inc., Great Neck L.I.N.Y.
	Chemistry Stores, Stanford University, Stanford Ca. 94305, (415)497-1277
Borg	Borg-Warner Chemicals Inc., International Center, Parkersburg, W. Va. 26101 (304)424-5411
	Colpitts Plastics Co., 181 Railroad Ave., Richfield N.J. 07457
C	Serac, PO Box 1178, Milwaukee, Wis. 53281, (414)289-9888
Ch	Chastel, Hayward, Ca., (415)785-8338
Ciba	Ciba-Alcalde Products
Corr	Corning Glass Works, S. Taaffe, Bunnvale, Ca., (408)732-5858
	Corning Glass, Corning, N.Y.
CVS	Local pharmacy
D	E.I. Dupont de Nemours, MS333 Freon Products Div., Wilmington, Del. 19880 (609)441-7515
	Ventron Corp., Alpha Products, 2098 Pine St., San Leandro, Ca. 94577
	Pantron Corp., Alpha Division, Dover, Mass., (617)777-1971x485
DC	Dow Corning, (everything is silicon based) Fresno, Ca. (209)4418281
	K. R. Anderson, 136 Wolfe Rd., Sunnyvale, Ca. 94086 (408)734-6738
	Bronell Electro Products (212)924-3488
Dyna	Dynasil Corp., Cooper Rd., Berlin, N.J. 08001 (609)767-4608 Marty Sersoff
E	E. T. Horn Co., 511 66th Ave., Oakland, Ca. 94621, (415)568-2737
	Dow Chemical
EEL	EEL, 91 Tolland St., East Hartford, Conn. 06188, (203)289-5428
	Fernitron, 232 Forbes Rd., Bedford, Ohio 44146, (216)232-8188
	Wolfe Engineering, (714)645-7214
	Channel Industries, 839 Ward Dr., Santa Barbara, Ca. 93103, (805)967-8171
	Transducer Products, Rt 63 North, Boshon, Conn., (203)491-3251
Echo	Echo Labs, PO Box 552, Lewiston, Penn. 17844, (717)248-4993
EC	Emerson Cummings, 684 W 182nd St., Gardena, Ca. 90248, (213)329-1947, (213)321-6650x33
F1	Fluorocarbon Process Systems, 1432 S Allec St., PO Box 3648, Anaheim, Ca. 92803, (714)956-7338
Gall	Gallagher Corp., 3966 Morrison Dr., Evanston, Ill. 60031 (312)249-3448 Richard Gallagher
GE	General Electric, Silicon Products, Waterford, N.Y. 12188, (518)237-3338
	Electrical Specialty Co., 213 E. Harris Ave., So. San Francisco, Ca. (415)589-9611
SEP	General Electric, 1700 E. Balp, City of Industry, Ca. 91745
ER	E.V. Roberts and Associates, Palo Alto, Ca., (415)494-1671
	E.V. Roberts and Associates, 8588 Stellar Dr., Culver City, Ca. 90236

TABLE I (Continued)

	Hankel Corporation
	General Mills
H	Hycol Division, Dexter Corp., Olean, N.Y. 14768
	Hycol Insulating Materials, 15851 E. San Julian Rd., Industry, Ca. 91749, (213)968-6511
	(415)687-4281
I	Indiana Corp., PO Box 249, Utica, N.Y. 13503, (315)797-1438 Telex 537362
JK	Johns-Manville
	Electrical Materials Inc., San Antonio Rd., Palo Alto, Ca. (415)494-8428
Kara	Karacis Inc., 184 N. Church, Linton, Ind. 46149
Kodak	Kodak Chemical Products Inc., Kingsport, Tenn.
Lee	Lee Plastics, 795 E. Pico Blvd., Los Angeles, Ca. 90021, (213)746-5984
LI	Li Tungsten Co., 63 Herhill Rd., Glen Cove, N.Y. 11542, (516)676-1314
Loc	Lochic Supply, 2950 Bay Rd., Redwood City, Ca. 94063, (415)364-7338
	Loctite, 18731 Cranwood Parkway, Cleveland, Ohio 44128, (888)321-5188, 89
HPC	Medical Products Corp., PO 1274, Racine, Wisc. 53405, (414)634-1556
Mobay	Mobay Chemical Corp., 16661 Von Karman Ave., Irvine, Ca. 92714
Mons	Monsanto Co., 888 W. Lindbergh Blvd., St. Louis, Mo. 63166 (314)674-1800
Mura	Murata Corp. of America, 148 Franklin Rd. S.E., Marietta, Ga. 30067, (404)952-9777 Jiro Miyazaki
Phil	Phillips Petroleum
Port	Port Plastics, 1847 N. Fair Oaks Ave., Sunnyvale, Ca. 94086 (415)324-1391, (408)744-1111
PRC	Products Research and Chemical Corp., 5438 San Fernando, Glendale Ca. 91203
Ren	Ren Plastics, Div. of Ciba Belgis, 18424 Mt Langley, Fountain Valley, Ca., (714)963-8784
RG	Royal Glass, 458 Cambridge Ave., Palo Alto, Ca., (415)321-5518
Roba	Roba and Maas
RS	R. S. Hughes Co., 1462 Sonora Court, PO Box 515, Sunnyvale, Ca. 94086 (408)739-3213
	Electrical Specialties Co. (415)537-5611
Schott	Schott Optical Glass, PO Box 4111, Fullerton, Ca. 92634, (714)871-8888 Bob Chasberlin
	Schott Optical Glass, Markt Ave., Duryea, Penn. 18642, (717)457-7485
Sh	Shell Chemical Co.
SW	Sargent Welch Chemical Corp.
T	Thiokol Chemical Div., 938 Lower Ferry Rd., Trenton, N.J. 08647, (609)396-4281
Tap	Tao Plastics Inc., 1212 Alameda, San Jose, Ca., (408)292-6885
Tech	Techform Labs, Los Angeles, Ca. 90061
Tr	Tracum Inc., Bedford, Ma. 02153
UC	Union Carbide
Uni	Unroyal (888)243-2219
Upjohn	Upjohn Co., CPR Div., 555 Alaska Ave., Torrance, Ca. 90583
USI	USI Corp. c/o Plastic Systems, 50 Brigham St., Marlboro, Ma. 01752 (617)483-7398
VF	Valley-Fisher, 75 South St., Hopkinton, Ma 01748 (617)435-6831
VR	Van Waters and Rogers, (408)261-9788, 2256 Junction, San Jose, Ca.
Wa	Wadsworth-Pacific, (415)321-3619
	Epoxy Technology Inc., 14 Fortune Dr., Billerica, Mass. 01821
WG	Westara Gold and Platinum Co., 477 Harbor Blvd., Belmont, Ca. 94002, (415)592-9448
WP	Westlake Plastics, PO Box 127, Lemhi, Penn. 19852, (215)459-1888 Hatsu, N.Y., N.Y.
	Plastic Sales, San Francisco, Ca. (415)558-1848

OTHER APPROPRIATIONS

ALUMINA	Aluminum oxide for thin layer chromatography. Obtained from Chemistry Stores at Stanford University.
CSM	A Li Tungsten product, the 6 to 18 micron powder
DEM	Dow epoxy hardener
LPS	A liquid polysulfide resin from Thiokol Corporation
PER	Dow epoxy resin
MPDA	Meta-phenaline-dianiline, a good epoxy hardener. Use vendors B, handle, or rather don't handle with care. This product can be difficult to obtain fresh, should arrive in the form of whiteish flakes. When handling, take care to use gloves and apron, do not breath the powder. It is best stored in jars filled with dry nitrogen at 8C. When opening a new jar, allow it to equilibrate to RT first.
PHA	Parts per hundred parts by weight of A
PHE	Parts per hundred parts by weight of sized epoxy
PNR	Parts per hundred parts by weight of RESIN, as opposed to total weight etc.
R1	Recipe 1: Heat the resin to 78C, add the MPDA and keep the mixture in the oven until the MPDA melts. Sift the W through a 100 mesh screen and add to the epoxy. Stir thoroughly, and outgass the mixture to a 100 micron vacuum. Cure at 18C for 1 hour, then leave in oven overnight at 78C.
R2	Recipe 2: Mix alumina to resin. Alumina is very light and fluffy and does not need to be sifted first. It is so light in fact, that any mixture having more than about 100PNR of it will be fixotropic and hard to pour. Next add the hardener, then stir thoroughly and outgass to 220 microns. Use an engraving tool on the beaker to facilitate pouring. Cure at RT for 48 hours.
R3	Recipe 3: Sift the W through a 100 mesh screen before adding to the resin at RT. Stir and outgass the mixture to 150 microns vacuum. Add the hardener, stir and outgass again. We have noted that epoxy hardened by DEM20, if exposed to the atmospheric moisture, will still be sticky after curing. This is called blushing and usually does not effect the experiment.

SELFRIDGE: APPROXIMATE MATERIAL PROPERTIES IN ISOTROPIC MATERIALS

393

TABLE I (Continued)

84	Recipe 4: Mix parts A and B and filler together, outgass to 100 microns vacuum, bake overnight at 78C.
85	Recipe 5: Vacuum impregnation. To make these materials a vessel is required which is vacuum tight at the bottom and open at the top, i.e. a test tube or jig. The jig is cold released and the filler material is poured into it, usually no more than a third of the way to the top. Next the jig is warmed in an oven to the specified temperature to preheat it and bake on the cold release. The resin is melted, usually in the same oven at this time, and then the NPDA is added and allowed to melt into the resin. Thiolol may also be added at this time if specified. The mixture is stirred, then poured over the filler material, usually no more than two thirds of the way to the top. This assembly is outgassed till a vacuum of 100 microns is reached, usually in about 10 minutes depending on the size of the jig etc. Then the vacuum is broken, the epoxy is forced into the filler material by atmospheric pressure. Bake at 78C overnight.
86	Recipe 6: Parts A and B are stirred together, outgass to 100 microns vacuum, bake at 68C overnight.
87	Recipe 7: Same as 86 but the material is post baked at 200C overnight. Material turns from red to black and the loss increases.
88	Recipe 8: Stir components together thoroughly, outgass to 200 microns, pour into a jig at room temperature, leave at RT for about an hour, then place jig in 72C oven overnight.
89	Recipe 9: Stir components together thoroughly, outgass to 200 microns, pour in to a preheated jig and bake at 98C overnight.
918	Recipe 10: Melt resin, stir in alumina, outgass six to ten, add DEK20, stir, outgass again to ten.
RT	Room temperature, or about 28C
SiC	Silicon carbide, 325 mesh or about 10 to 20 microns diameter, Cerac product number 51167
Ti167	325 mesh tungsten from Cerac, product number Ti167
V148	Versamid V148
W	Tungsten powder, 1 to 2 microns diameter, Cerac product number Ti166
	This material is very fine and does not settle out of a heavier epoxy resin such as E8317 at RT

REFERENCES

- 45 Handbook of Tables for Applied Engineering Sciences
 46 Alan Selfridge, Ph.D., Ultrasonic Devices, 1992 Piedmontic Co., Palo Alto, Ca. 94303 415:327-1148
 47 Handbook of Chemistry and Physics, 45th Edition, Chemical Rubber Co., Cleveland Ohio, pg E-25
 48 San Francisco, Ph.D., Sonotronics, Sunnyvale, Ca.
 49 Genevieve Bonas, IEEE Transactions on Sonics and Ultrasonics, Apr 1983
 50 John Fessenden, Ph.D.
 51 Kinsler and Frey, FUNDAMENTALS OF ACOUSTICS, John Wiley and Sons, 1962
 52 JACOB T. BURNGSTEIN, Numerical Data and Functional Relationships in Science and Technology, New Series
 53 SCF 11: Atomic and Molecular Physics
 54 VOLMER St Molecular Scattering on W. Schaeffle
 55 EDITOR: R. M. Melville and A. P. Melville
 56 MELVILLE: Reinhold Publishing, Berlin, Heidelberg, New York, 1967
 57 This reference contains reliable and complete information for just about any organic liquids. Other volumes in this work contains such information on various anisotropic solids and crystals.
 58 Ferroalloy Inc., P.O. Box 5528, Portland, OR 97208 503:585-2627 Fax: 503:587-1557 Application Note 25
 59 Patents Engineering, Dec 1950
 60 Rick Ezer, Ph.D., Hewlett Packard, Page Mill Rd., Palo Alto, Ca.
 61 Simmons, Gern 1971- Single crystal elastic constants and calculated aggregate properties
 62 1973: by Gene Simmons and Herbert Wang, 2nd ed. Cambridge, Mass. M.I.T. Press (1971) ex 370 ocs.

used for column headings here:

Loss	Attenuation
ρ	density in g/cm ³
σ	Poisson's ratio or $(1 - 2X)/(2 * (1 - X))$ where $X = (V_s/V_L)^2$
$\Delta V/\Delta T$	change of velocity per change in temperature given in m/s/°C referenced to 25°C.
V_L	acoustic longitudinal wave velocity in mm/ μ s
V_s	acoustic shear wave velocity in mm/ μ s
Z_L	acoustic impedance = $\rho * V_L$, in kg/(s * m ²) * 10 ⁻⁶ .

LOSS, or attenuation, is given in several different formats in these tables. The most specific way is with the @ symbol. The number before the @ is the loss in dB/cm, the number after the @ symbol is the frequency at which the attenuation was measured in MHz. The use of A =

means the number given is alpha (nepers per cm) given in s²/cm times 10⁻⁷. To get loss in dB/cm multiply alpha by 8.686 * f², where f is the frequency of interest in Hz. This representation obviously assumes that loss increases in proportion to frequency squared, and is most commonly used for low loss materials such as glass.

Transducer modeling programs will commonly assume loss increases just in proportion to the frequency to the first power. If this is the case then it is appropriate to use the material quality factor, or acoustic Q. To convert between dB/cm and Q the following equations can be useful:

$$Q = \frac{2 * \pi * (\text{Stored energy})}{\text{Energy dissipated per cycle}} \quad (10)$$

$$Q = W_0 \frac{\text{Stored energy}}{\text{Average power loss}} \quad (11)$$

$$Q = \frac{86.9 * \pi * f}{((\text{dB/cm}) * \text{velocity})} \quad (12)$$

REFERENCES


- [1] B. A. Auld, *Acoustic Fields and Waves in Solids*, vol. I and II. New York: John Wiley, 1973.
- [2] V. M. Ristic, *Principles of Acoustic Devices*. New York: John Wiley, N.Y., 1983.
- [3] Fred Stanket, Schlumberger, Inc., Ridgefield, CT, private communication.



Alan R. Selfridge was born on February 27, 1954 in Midland, MI. He received the B.S. degree from the University of California at Davis in biomedical engineering in 1976, and the Ph.D. degree from Stanford University, Stanford, CA, in electrical engineering in 1983. His thesis work was on the design and measurement of ultrasonic transducers and transducer arrays.

He is currently self employed in Palo Alto, CA as a consultant in the design, fabrication, and measurement of ultrasonic devices. His primary career goal is to develop the state of the art in medical imaging so as to enable better prediction of birth defects.

Dr. Selfridge is currently the chairman of the Santa Clara Valley Group on Sonics and Ultrasonics.



-621-04927-5

¥1200E

本体1,200円十税)



1923040012002

天文学年表 (Chronological Scientific Tables),
National Astronomical Observatory (ed.), Maruzen Co., Ltd.

平成14年
2002

文部科学省 国立天文台



統計



丸善株式会社

Your Ref No.: 10873.1804USWO
Our Ref No.: H2353-05

Viscosity of Liquids ($10^{-3}\text{Pa}\cdot\text{s}$, Pressure 1atm=101.325Pa)

Material	0°C	25°C	50°C	75°C	100°C
Acetone	0.402	0.310	0.247	0.200	0.165
Aniline	9.450	3.822	1.982	1.201	0.808
Ethanol	1.673	1.084	0.684	0.459	0.323
Diethyl Ether	0.288	0.224	0.179	0.146	0.119
Carbon Tetrachloride	1.341	0.912	0.662	0.503	0.395
Hg	1.616	1.528	1.401	1.322	1.255
Castor Oil	—	700	125	62.0	16.9
Benzene	—	0.603	0.436	0.332	0.263
Methanol	0.797	0.543	0.392	0.294	0.227
Carbonic Acid	—	23.8	11.7	6.6	4.1